

Canon Camera Connect

Some of our Canon cameras can be connected to your smartphone!

Cameras with this ability are:

- Canon EOS Rebel T7i
- Canon EOS Rebel T6i
- Canon PowerShot SX60

Once connected, your phone can be used as a remote to take photos and record video, then those photos or videos can be quickly and easily transferred to your phone straight from the app!



Step 1: Download the free Canon Camera Connect app (App Thumbnail Shown at right) from either the Google Play Store or the Apple App Store. Make sure you download the one made by Canon and not a third-party.

Step 2: Open the app and follow its instructions. Cameras can be connected through either Bluetooth, NFC, or Wi-Fi. It will attempt to connect in that order, so if one doesn't work then just keep going through the instructions.

Step 3: To disconnect your phone from the camera, simply turn the camera off. If you do not want your phone to be associated with that camera anymore, then you will have to delete it from the camera manually.

Type of Wireless Connection

Bluetooth is a short-range wireless technology standard for exchanging data. Cameras with Bluetooth capability will have this symbol:



NFC or **Near-field communication** is a set of communication protocols that enable two electronic devices, one of which is usually a portable device such as a smartphone, to establish communication by bringing them within 4 cm (1.6 in) of each other. Cameras with NFC capability will have this symbol:



Wi-Fi is the most standard of wireless connections, it allows for LAN (local area network) connections between devices. Usually this is between a phone or laptop and a router to allow internet access, but if two electronic devices both have wireless capabilities then they should be able to connect to each other. Wi-Fi has a longer range than both Bluetooth and NFC. Cameras with Wi-Fi capabilities will have this symbol:

